



PEYDEN WEIGHBRIDGE PROGRAM

FOR DETAILED INFORMATION ABOUT
THE PROGRAM AND TO REQUEST A
LICENSE



info@peykan.com.tr



www.peykan.com.tr



+90 224 256 07 39

Contens

Contens.....	2
Login Screen	3
General Settings.....	3
Plug Settings	4
Programming Language.....	5
Weighing Port.....	5
Pending Vehicles	6
Vehicle Entry Form.....	6
Vehicle Release Form.....	8
Customer Definition.....	12
Program License Creation Request	13

Login Screen



The login screen is the first screen we will encounter in the program. A login password is required to use the program. We log in using the password of the user we created.

General Settings

Genel Ayar

ŞİFRE SORSUN : Evet Kapat

YÜKLEME İSTASYONU : Evet Kayıt

MÜŞTERİYE AİT ARAÇLAR : Evet

Çıkış Yerini : Göster Mal Cinsi: Gösterme

Manuel Giriş : Var Yazdırma : Göster

Ağırlık Girişi Formatı : X.XX XX.X XXX

Çıkış Fiş No : 889 **Giriş Fiş No :** 10004

Fiş Çıktısındaki Ayarlar

Ust Bölge :

1. Sol : 80 Ust : 13 Aralık : 30

2. Sol : 180 Font Size : 9


Alt Bölge :

1. Sol : 80 Ust : 130 Aralık : 40

2. Sol : 200 Font Size : 12

In this section, you can configure settings such as password prompting, goods loading station, manual entry, and customer-owned vehicles. You can also adjust the page layout of the printed receipt from this section. After making all the settings, you must press the save button. If you wish to exit without completing the process, you can close the window using the close button.

Plug Settings




The screenshot shows the 'Fiş Ayarlama' window with the following details:

- Fiş AYARLARI:**
 - Firma Adı: PEYKAN YAZILIM
 - TEL: 0224 256 07 39
 - www.peykan.com.tr
 - FİŞ NO.....0000....: {FISNO}
 - PLAKA NO..56aab10.....: {PLAKANO}
 - KANTAR MEMURU....jijijij.: {KANTARMEMURU}
 - MALIN CİNSİ....mal...: {MALCINSI}
 - MÜŞTERİ....m1.....: {MUSTERIADI}
 - İLK TARTIM :
 - SON TARTIM :
 - NET TARTIM :
- DEĞİŞKEN LİSTESİ:**
 - PLAKA NO
 - FİŞ NO
 - GİRİŞ TARİHİ
 - GİRİŞ SAATİ
 - GELDİĞİ YER
 - KANTAR MEMURU
 - ŞOFÖR ADI
 - MALIN CİNSİ
 - MÜŞTERİ ADI
 - GİDECEĞİ YER
 - ÇIKIŞ TARİHİ
 - ÇIKIŞ SAATİ
- Çıkış Fiş No :** 889
- Giriş Fiş No :** 10004
- Buttons:** D.AYARLAR, KAYDET, KAPAT

In this section, you can adjust the necessary changes to the printed receipt. Companies can specify names and create designs according to their own requests and customers. After making all the adjustments, you need to press the 'Save' button. If you wish to exit without making any changes, you can use the 'Close' button.

Programming Language



You can change the program's language from this section. There are two language options: English and Turkish.


Weighing Port



When you click on the "Weighing Port" option, a window opens where you can configure the scale's communication settings. The .COM settings show the port name to which the weighing device is connected to the computer. You can disconnect using the 'Disconnect' button and reconnect using the 'Connect' button. Don't forget to save the changes.


Pending Vehicles

Vehicles on hold are those that have completed the entry process but have not yet completed the exit process.



Fiş No	Plaka No	Giriş Tarihi	Giriş Saati	Kantarcı Adı	Şoför Adı	İlk Tarım	Geliş Yeri
10002	16 ABC 10	04.03.2026	13:56:20	LLLLLL	AAAAAA	4060	KKKKK
10001	56 YBN 89	04.03.2026	11:38:58	BBBBB	FFFFF	10000	AAAA
10000	16 ASD 22	04.03.2026	10:37:19	CCCC	AAA	15000	BBB

Vehicle Entry Form



2026 - Haziran : 15 - Pazartesi - 15:44:38

İLK TARTIM : 00000 Kg

Plaka no :

Şoför Adı :

Geldiği Yer :

K. Memuru :

KAYIT

Fiş ve KAYDET


Kapat

Sabit Dara Kayıt

Giriş Fiş No : 10004

This is the area where the vehicle's initial weighing is performed and the necessary information is entered into the system. License Plate Number: This is where the license plate number of the vehicle to be entered is entered. Driver's Name: The driver's name of the vehicle being entered is entered. Direction: The location from which the vehicle arrived. Weighbridge Operator: The weighbridge operator who performed the weighing is selected. Receipt Number: This is the receipt number created for the entry process. It automatically increases after each transaction. We register the vehicle with a fixed tare weight using the 'Fixed Tare Weight Registration' button. Receipt and Save: We can create a vehicle entry receipt.

In this section, the program automatically retrieves the weights from the scale, but to avoid interruptions in your work in case of any problems, you can also manually enter the weights by double-clicking to the right of the section that says "Initial Weighing".



After making all the adjustments, you need to press the "Save" button. If you wish to exit without making any changes, you can also exit using the "Close" button.

Vehicle Release Form

Araç Çıkış Formu

2026 - Haziran : 15 - Pazartesi - 16:15:44

SON TARTIM : 00000 Kg

Plaka no :

Giriş Tarihi :

Giriş Saati :

Geldiği Yer : ..

K. Memuru :

Şoför Adı :

Müşteri Adı :

Gitiği Yer :

İlk Tartım : 00000


Net Tartım : 00000

Fiş No : 889

This form is used to record the entry and exit of products from the stock where the vehicle's last weighing was performed, and to generate an exit slip. License Plate Number: Enter the license plate number of the vehicle to be exited. Entry Date: The date the vehicle's entry record was created is retrieved from the system. Entry Time: Shows the time the vehicle entered. Weighbridge Operator: Select the weighbridge operator. Customer Name: You can define this from the customer definitions in the program parameters. You can transfer fixed tare weight vehicles by clicking the 'Search' button. To perform this operation, you must click the 'Transfer' button. Registration: When you click the Registration button, the vehicle's exit is completed. Vehicles Entering: Shows the vehicles that are waiting.

Kayıtlı Araç Sayısı = 5

SABİT DARA DOSYASI

Plaka no Gir : 

Plaka No	Giriş Tarihi	Giriş Saati	Kantarçı Adı	Şoför Adı	İlk Tartım	Geliş Yeri
16 ASD 22	04.03.2026	10:37:19	CCCC	AAA	15000	BBB
56 YBN 89	04.03.2026	11:38:58	BBBB	FFFF	10000	AAAA
16 ABC 10	04.03.2026	13:56:20	LLLLLL	AAAAAA	4060	KKKKK
16 ZEY 34	04.03.2026	14:34:08	ALİ	ZEYNEP	3940	İSTANBUL
14 SDS	04.03.2026	10:36:06	BBBB	DDDD	8000	AAA

 **Değiştir**
 **Aktar**
 **Kapat**

Fixed Tare Vehicles: Displays vehicles with a fixed tare weight. You can transfer fixed tare weight vehicles to the vehicle output form using the 'Transfer' option. You can make changes to our fixed tare weight vehicle using the 'Change' button.

Report

Genel Rapor

Yazdır Excel İnter Pdf Tekrar Fiy Yükle

İkiş Tarihi : 15.06.2026

FİŞ NO 889

Mevcut Tartım Sayısı: **Net Tartım Toplam Kg 3.360,00 Kg**

Fiy No: 889
 Kantar Numuru: ALİ
 Plaka No: 16 ZEY 34
 Şoför Adı: AAA
 Oluşt. Yeri: İSTANBUL
 Giriş Tarihi: 04.03.2026
 Giriş Saati: 14:34:08

İstat. Cinsi:
 Müşteri Adı: Zeynep
 İlk Tartım: 3.940
 Son Tartım: 580
 Çıkış Yeri: BURSA
 Çıkış Tarihi: 04.03.2026
 Çıkış Saati: 14:36:28
Net Kg: 3.360


Fiy No: 16 ZEY 34
 Şoför: AAA
 Geliş Yeri: İSTANBUL
 Geliş Tarihi: 04.03.2026
 Geliş Saati: 14:34:08
 Müşteri: Zeynep
 Çıkış Yeri: BURSA
 Çıkış Tarihi: 04.03.2026
 Çıkış Saati: 14:36:28
 İlk Kg: 3940
 Son Kg: 580
 Net Kg: 3360

Kapat KAYIT 1

The General Reporting Screen is the section that allows for the collective viewing, querying, and reporting of all weighing operations performed on the

weighbridge system. Through this screen, users can list recorded input and output weighings according to specific date criteria, review record details, and export the required reports in various formats. Tools for reporting operations are located at the top of the screen. Users can print generated reports directly, export them in Excel, HTML, or PDF formats, and reprint previously created receipts. Thus, both digital and physical reporting processes can be easily carried out. Records can be filtered by date on the reporting screen. Users can choose to view only records for the current date, perform a query by selecting a specific date, or list all records in the system. This feature allows for quick access to past weighing operations and easy retrieval of desired information. Detailed information for the selected record is displayed at the top of the screen. This section displays the receipt number, weighbridge operator, vehicle license plate, driver information, customer name, type of goods, arrival and departure points, arrival and departure date and time information, as well as the initial, final, and net weight values. Thus, the user can access all information related to any record from a single screen. The lower section of the screen lists the records obtained from the query in a table. For each record, the receipt number, vehicle license plate, driver name, customer information, arrival and departure information, and weighing results are shown in separate columns. When the user selects the desired record from the list, the details of the selected record are automatically displayed in the upper section. The system automatically calculates the net weight using the initial and final weighing values.

Definitions



The selection area at the top of the screen lists the information that can be defined in the system. The user can select from predefined fields such as customer name, weighbridge operator, driver name, license plate number, type of goods, origin, and destination. The selected field is added to the record list and made available for use in the system. The list area in the middle of the screen shows the previously defined boxes. This list allows the user to view the fields actively used in the system and track the definitions made. The defined fields are used in record entry screens and reporting processes, helping to maintain data in a standardized manner. The definitions are saved to the system with the Save button on the right, while the Close button closes the screen without making any changes.

Customer Definition

Kayıtlı Araç Sayısı = 1

MÜŞTERİ ARAÇLARI VE BİLGİLERİ

No	Müşteri Firma	PALAKA	Şofer Adı	Yer
1	ZEYNEP	16 ASD 22	ALİ	BURSA

Plaka no Gir : 16 ASD 22  

Yeni Müşteri Kayıtı

Şofer : PLAKA :

Müşter :

Adres :

 KAYIT


The Customer Definition screen is used to record customer companies and their vehicle information that will be processed in the weighbridge system. Registered customer and vehicle information can be viewed, searches can be performed by license plate number, and new customer records can be created through this screen. Defining customer, driver, license plate, and address information in the system speeds up data entry during weighbridge operations, reduces duplicate registration processes, and ensures more organized processing.


Program License Creation Request






----- [1882547943] -----

Firma :

Şifrenizi Giriniz : Windows User



 DEMO VERSİYON

 Email  Tamam  Vazgeç  Yardım  Kayıt Ol

When you first open Peyden, it runs as a Demo Version. To use the full version of the program, you must initiate the license request process by using the "Register" option on the main screen.

Aktivasyon Kodu İsteği

Ad Soyad: *

E-posta: *

Telefon: *

Bilgisayar :

Firma : *


Program : *

Versiyon : *

Kod : *

Gönder

Clicking the "Register" button opens the Activation Code Request screen. This screen contains the user's full name, email address, phone number, company information, and a unique code generated by the system for the computer. After filling in the required fields, the application is submitted. Once the license request is reviewed, a unique activation code will be generated and shared with the user. Licensing is completed upon entering the activation code.



- 1) Enter the company name on the screen that opens.
- 2) Enter the license code in the area indicated by the red arrow.
- 3) Uncheck the Demo version option.
- 4) Click the OK button.
- 5) The program can now be used with a license.